

SAMSUNG

中文 / English



HEADSET

WEP490

MOBILE ENHANCEMENT

中文	1
English.....	17

目錄

入門

耳機相關概述	3
按鈕功能	4
耳機充電	5
佩戴耳機	7

使用耳機

開啓／關閉耳機電源	8
配對與連結耳機	9
使用通話功能	11

附錄

常見問題	13
保固與零件更換	14
規格	15

使用 WEP490 藍牙耳機之前，請先花些時間通閱本使用手冊。

Bluetooth® 係 Bluetooth SIC, Inc. 的註冊商標 — Bluetooth QD ID: B015890

有關 Bluetooth 的詳細資訊，請上 www.bluetooth.com 查詢。



安全措施

- 本機限在不干擾合法電臺與不受被干擾保障條件下於室內使用。
- 切勿因任何原因拆卸或改裝本耳機，否則可能會造成耳機故障或燒壞。需維修或更換電池時，請將藍牙耳機送至授權維修中心。
- 如需在開車時使用耳機，請遵守所在國家或地區的法律。
- 請避免將耳機存放在高溫 (50 °C / 122 °F 以上) 之處，例如高溫的車內或日光直射處，否則會損壞效能和降低電池使用壽命。
- 請勿讓耳機或任何隨附的零件淋雨或接觸液體。



耳機音量過大時，長時間使用可能會傷害聽力。

入門




本節將說明藍牙耳機的正確使用方式。

耳機相關概述



請確定耳機是否隨附下列配件：
旅行充電器、使用手冊、耳鉤。
耳機隨附的物品可能視地區而有所不同。

按鈕功能

按鈕	功能
 電源	滑動此開關即可開啓或關閉耳機電源。
 通話	<ul style="list-style-type: none">• 按下即可撥打或接聽電話。• 按下即可結束通話。• 按住可進入 [配對] 模式
 音量	<ul style="list-style-type: none">• 按一下可調整音量。• 按住可開啓或關閉麥克風電源。

耳機充電

本耳機內建無法取出的可重複充電電池。請確定在第一次使用耳機前，電池能量已經充滿。

- 1 將旅行充電器較小的一端插入充電插孔。



- 2 將旅行充電器較大的一端插入電源插座。
在充電期間，指示燈將會變成紅燈。若充電尚未開始，請將旅行充電器的插頭拔掉並再次插上。
- 3 耳機充滿電時，指示燈會變為藍色。請將旅行充電器的插頭從電源插座與耳機上拔下。



- 僅能使用 **Samsung** 核可的旅行充電器。未經授權的旅行充電器可能導致爆炸的危險或使耳機受損。
- 在非常高的溫度下為耳機充電時，紅色的指示燈會閃爍且會停止充電。這是正常情況，可保護耳機不受到損害。將旅行充電器自耳機上拔下。通常，可在低於 50°C/122°F (±5°C/9°F) 溫度下為耳機充電。
- 由於電池為耗材，在充電或放電後，電池電力會逐漸耗損。
- 充電時將無法使用耳機。充電完畢後，請嘗試連結。

檢查電池電量

同時，請按住降低音量按鈕與通話按鈕。視電池電量而定，指示燈會以下列其中一種色彩閃爍 5 次：

電池電量	指示燈色彩
高於 80%	藍色
80~20%	紫紅色
低於 20%	紅色

電力不足時

耳機會發出嗶聲，並閃爍紅色指示燈。請將電池重新充電。若在通話過程中耳機電源關閉，通話將會自動切換至手機。

佩戴耳機

將耳機戴在耳朵上。

可視想要佩戴耳機的耳朵，對耳鉤做相應調整。



▲ 左側



▲ 右側



使用耳機

本節說明如何開啓耳機電源及與手機配對和連接，以及各種功能的使用。



- 可用的功能和特性可能會依手機的類型而有所不同。
- 有些設備，尤其是未經 **Bluetooth SIG** 測試及核准者，可能無法與您的手機相容。

開啟 / 關閉耳機電源

- 滑動此開關  即可開啓耳機電源。藍色指示燈會閃爍 4 次。
- 滑動此開關  即可關閉耳機電源。藍色與紅色指示燈會同時閃爍。

配對與連結耳機

配對作業將會在兩個具備藍牙功能的裝置之間（例如您的藍牙手機和藍牙耳機）建立唯一且加密的無線連結。

若要将耳機搭配其他藍牙裝置使用，必須先讓兩個裝置進行配對。配對時，請保持耳機與手機適當靠近。配對完成後，就可以連接這兩個裝置了。

將耳機與手機配對及連結

- 1 進入配對模式。
 - 請按住通話按鈕再打開耳機電源，直到指示燈在閃爍後持續亮著藍燈。
 - 第一次啟動耳機時，耳機即自動進入配對模式。
- 2 啓用手機的藍牙功能，並搜尋耳機（請參閱手機使用手冊）。
- 3 從手機的裝置清單中選擇耳機（WEP490）。
- 4 輸入藍牙 PIN 碼（0000，4 個 0），將耳機配對和連接至您的手機。



本耳機支援簡易配對功能，可讓耳機無需 PIN 即可與手機進行配對。與藍牙 2.1 版本或更新版本相容的手機皆具有此項功能。

斷開耳機連結

若要斷開手機與耳機的連結：

- 關閉耳機。
- 使用手機上的藍牙功能表。

重新連線耳機

耳機與手機配對後，每次開啓耳機時，耳機即會自動嘗試重新連結。

若耳機未自動嘗試重新連結，

- 請按下通話按鈕。
- 使用手機上的藍牙功能表。

撥打電話

重撥最後一個號碼

請按下通話按鈕以重撥最後一個號碼。

在某些手機上，按下此通話按鈕即可開啓通話記錄清單。請再次按下通話按鈕以撥打選取的號碼。

聲控撥號

請按住通話按鈕，然後說出姓名用語音撥號。

接聽來電

聽到來電鈴聲時，按下通話按鈕即可接聽電話。

結束通話

按下通話按鈕，即可結束通話。

拒接來電

有來電時，按住通話按鈕即可拒接來電。

在通話中使用選項

您可使用下列功能控制通話：

麥克風靜音

按住音量控制按鈕即可將麥克風關閉，使通話對方無法聽到您的聲音。麥克風關閉時，耳機會定時發出嗶聲。再次按住音量控制按鈕，即可取消麥克風靜音。

將通話從手機轉接至耳機

按下通話按鈕，即可將通話從手機切換至耳機。

保留來電

按住通話按鈕，即可保留目前的通話。

接聽第二通來電

- 聽到待接通話時，按下通話按鈕即可結束第一通電話，並接聽第二通來電。
- 聽到待接通話時，按住通話按鈕即可保留第一通電話，並接聽第二通來電。
- 若要在目前的通話與保留的來電之間切換，請按住通話按鈕。

附錄

常見問題

本耳機是否適用於筆記型電腦、個人電腦和 PDA？	本耳機可搭配支援相同藍牙版本與模式的裝置使用。如需規格的詳細資訊，請參閱第 15 頁。
通話中時，為何我不聽到聲音或者有干擾？	像無線電話或無線網路設備等裝置，都可能出現干擾情形，通常是無聲。為減少干擾，請讓耳機遠離會使用或可產生電波的裝置。
本耳機是否會干擾車上的電子設備、收音機或電腦？	本耳機發射的信號符合國際藍牙標準規範。因此，標準家用電子設備並不會受到任何干擾。
其他的藍牙手機使用者是否會聽到我的通話內容？	耳機配對藍牙手機時，此兩個藍牙裝置之間會形成一個私人的無線溝通管道。由於藍牙無線信號的射頻功率比一般手機的射頻功率要小得多，因此本產品使用的無線藍牙技術不易遭第三者監聽。
通話中時，為何我聽到迴音？	請調整耳機音量，或移至其他區域再試一次。

我該如何清理耳機？	請使用柔軟的乾布擦拭。
藍牙耳機未充滿電。	旅行充電器未正確插入耳機。請將耳機自旅行充電器上拔除，然後重新連接再充電。

保固與零件更換

自原購買日期起一年內，**Samsung** 保證此產品在材料、設計與工藝上皆無瑕疵。
(保固期視各國情況可能有所不同。)

若於保固期限內，在正常使用情況下證實本產品有缺陷，請您將產品送回至當初購買產品的零售商或合格的服務中心。**Samsung** 和指定維修公司之責任僅限於保固維修成本及／或元件更換。

- 限原消費者才能享有保固。
- 為享有適當的保固服務，您必須提供收據或其他購買證明。
- 若產品序號、日期碼標籤或產品標籤遭移除，或若產品曾遭未經授權之協力廠商濫用、不當安裝、修改或維修，則本公司無責任提供保固。
- 電池和其他配件等有使用期限的耗材皆不在保固範圍內。
- **Samsung** 對於產品運送過程所造成的損失或損毀，不負任何損害賠償責任。
對於未經授權的協力廠商對本公司產品所進行的任何維修工作，**Samsung** 均不提供保固。

規格

項目	規格說明
藍牙版本	2.1 + EDR
支援模式	Headset Profile (耳機模式) , Hands-free profile (免持聽筒模式)
操作範圍	可達 33 英尺
待機時間	可達 180 小時*
通話時間	可達 6 小時*
充電時間	約 2 小時*

* 視手機的類型和使用狀態而定，實際時間可能有所不同。

Contents

Getting started

Your headset overview	19
Button functions	20
Charging the headset	21
Wearing the headset	23

Using your headset

Turning the headset on or off	24
Pairing and connecting the headset	25
Using call functions	27

Appendix

Frequently asked questions	29
Warranty and parts replacement	31
Specifications	32

Take the time to read through this user manual before using WEP490 Bluetooth Headset.

Bluetooth® is a registered trademark of the Bluetooth SIG, Inc. worldwide—
Bluetooth QD ID: B015890

More information about Bluetooth is available at www.bluetooth.com.



Safety precautions

- Never disassemble or modify your headset for any reason. Doing this may cause the headset to malfunction or become combustible. Bring the headset to an authorised service centre to repair it or replace the battery.
- When using your headset while driving, follow local regulations in the country or region you are in.
- Avoid storage at high temperatures (above 50° C/122° F), such as in a hot vehicle or in direct sunlight, as this can damage performance and reduce battery life.
- Do not expose the headset or any of its supplied parts to rain or other liquids.



At very high volumes, prolonged listening to the headset can damage your hearing.

Getting started

This section explains the proper use of your Bluetooth headset.

Your headset overview






Make sure you have the following items with your headset:

Travel adapter, User manual, **Ear hook**.

The items supplied with your headset may vary depending on your region.

Button functions

Button	Function
 Power	Slide the switch to turn the headset on or off.
 Talk	<ul style="list-style-type: none">• Press to make or answer a call.• Press to end a call.• Press and hold to enter Pairing mode.
 Volume	<ul style="list-style-type: none">• Press to adjust the volume.• During a call, press and hold to mute the microphone.

Charging the headset

This headset has a rechargeable internal battery which is non-removable. Ensure that you fully charge the battery before using the headset for the first time.

- 1 Plug the small end of the travel adapter into the charger jack.



- 2 Plug the large end of the travel adapter into a power outlet.
During charging, the indicator light will turn red. If charging does not begin, unplug the travel adapter and plug it in again.
- 3 When the headset is fully charged, the indicator light changes to blue. Unplug the travel adapter from the power outlet and the headset.



- Use only a Samsung-approved travel adapter. Unauthorised travel adapters may cause an explosion or damage to the headset.
- When charging the headset in very hot temperatures, the red indicator light flashes and charging will stop. This is a normal event to protect the headset from damage. Unplug the travel adapter from the headset. You can charge the headset normally below 50°C/12°F (±5°C/9°F).
- The battery will gradually wear out while charging or discharging because it is a consumable part.
- The headset is not able to operate while charging. Try connecting after charging is completed.

Checking the battery level

At the same time, press and hold the Volume down button and the Talk button. Depending on the battery level, the indicator light flashes 5 times in one of the following colours:

Battery level	Indicator light colour
Above 80%	Blue
80 ~20%	Violet
Below 20%	Red

When the battery power is low

The headset beeps and the indicator light flashes red. Recharge the battery. If the headset powers off during a call, the call will be automatically transferred to the phone.

Wearing the headset

Place the headset on your ear.

Depending on what ear you are going to wear the headset, simply adjust the ear hook accordingly.



▲ Left



▲ Right



Using your headset

This section explains how to turn the headset on, pair and connect to the phone, and use various functions.



- Activated functions and features may differ depending on the types of your phone.
- Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your headset.

Turning the headset on or off

- Slide the power switch  to turn the headset on. The blue indicator light flashes 4 times.
- Slide the power switch  to turn the headset off. Both blue and red indicator lights flash.

Pairing and connecting the headset

Pairing will create a unique and encrypted wireless link between two Bluetooth-enabled devices, such as a Bluetooth phone and your Bluetooth headset.

To use the headset with other Bluetooth devices, the devices must be paired. When trying to pair the two devices, keep the headset and the phone reasonably close together. After pairing, you can connect the two devices.

Pairing and connecting the headset with a phone

- 1 Enter Pairing mode.
 - With the headset turned on, press and hold the Talk button until the indicator light stays lit.
 - When you turn on the headset for the first time, it automatically enters Pairing mode.
- 2 Activate the Bluetooth feature on your phone and search for the headset (see your phone's user manual).
- 3 Select the headset (WEP490) from the list of devices found by your phone.

- 4 Enter the Bluetooth PIN (0000, 4 zeros) to pair and connect the headset to your phone.



Your headset supports the Simple Pairing feature which allows the headset to be paired with a phone without requesting a PIN. This feature is available for phones that are compliant with Bluetooth version 2.1 or higher.

Disconnecting the headset

To disconnect the headset from your phone,

- Turn off the headset.
- Use the Bluetooth menu on your phone.

Reconnecting the headset

When the headset is paired with a phone, it will attempt to automatically reconnect each time you turn it on.

If the headset does not **automatically attempt to reconnect**,

- Press the Talk button.
- Use the Bluetooth menu on your phone.

Using call functions

Making a call

Redialling the last number

Press the Talk button to redial the last number.

For some phones, pressing the Talk button opens the call log list. Press the Talk button again to dial the selected number.

Dialling a number by voice

Press and hold the Talk button, and then say a name to dial a number by voice.

Answering a call

When you hear incoming call tones, press the Talk button to answer a call.

Ending a call

Press the Talk button to end a call.

Rejecting a call

When a call comes in, press and hold the Talk button to reject a call.

Using options during a call

You can use the following functions to control your call:

Muting the microphone

Press and hold the Volume up or down button to turn the microphone off so that the person with whom you are speaking cannot hear you. When the microphone is turned off, the headset beeps at regular intervals. Press and hold the Volume up or down button again to turn the microphone back on.

Transferring a call from the phone to the headset

Press the Talk button to transfer a call from the phone to the headset.

Placing a call on hold

Press and hold the Talk button to place the current call on hold.

Answering a second call

- When you hear call waiting tones, press the Talk button to end the first call and answer a second call.
- When you hear waiting tones, press and hold the Talk button to place the first call on hold and answer a second call.
- To switch between the current call and a held call, press and hold the Talk button.

Appendix

Frequently asked questions

Will my headset work with laptops, PCs, and PDAs?	Your headset will work with devices that support the same Bluetooth version and profiles. For specifications, see page 32.
Why do I hear static or interference while on a call?	Appliances such as cordless phones and wireless networking equipment may cause interference, which usually sounds like static. To reduce any interference, keep the headset away from other devices that use or produce radio waves.
Will my headset interfere with my car's electronics, radio, or computer?	Your headset emits signals that are in compliance with the international Bluetooth standard. Therefore, you should not expect any interference with standard, consumer-grade electronic equipment.

Can other Bluetooth phone users hear my conversation?	When you pair your headset to your Bluetooth phone, you are creating a private link between only these two Bluetooth devices. The wireless Bluetooth technology used in your headset is not easily monitored by third parties because Bluetooth wireless signals are significantly lower in radio frequency power than those produced by a typical mobile phone.
Why do I hear an echo while on a call?	Adjust the headset volume, or move to another area and try again.
How do I clean my headset?	Wipe it with a soft dry cloth.
The headset does not fully charge.	The headset and the travel adapter may not have been connected properly. Separate the headset from the travel adapter, reconnect, and charge the headset.

Warranty and parts replacement

Samsung warrants this product as free of defects in material, design and workmanship for the period of one year from the original date of purchase. (Depending on your country, the length of warranty may vary.)

If during the period of warranty this product proves defective under normal use and service you should return the product to the retailer from whom it was originally purchased or qualified service centre. The liability of Samsung and its appointed maintenance company is limited to the cost of repair and/or replacement of the unit under warranty.

- The warranty is limited to the original purchaser.
- A copy of your receipt or other proof of purchase is required for a proper warranty service.
- The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation, modification, or repair by unauthorised third parties.
- Specifically exempt from any warranty are limited-life consumable components such as batteries and other accessories.
- Samsung will not assume any responsibility for any loss or damage incurred in shipping. All repair work on Samsung products by unauthorised third parties voids any warranty.

Specifications

Item	Specifications and description
Bluetooth version	2.1+EDR
Support Profile	Headset Profile, Hands-Free Profile
Operating range	Up to 33 feet (10 metres)
Standby time	Up to 180 hours*
Talk time	Up to 6 hours*
Charging time	Approximately 2 hours*

* Depending on the phone type and usage, the actual time may vary.



MOBILE ENHANCEMENT

World Wide Web
<http://www.samsungmobile.com>

Printed in Korea
Code No.: GH68-25770A
TAI. 11/2009. Rev. 1.0